

BONECO
healthy air

TRADITION SINCE 1956
 A SWISS COMPANY

F120

MANUAL



READ AND SAVE THESE INSTRUCTIONS
LIRE ET SAUVEGARDER CES INSTRUCTIONS
LEA Y GUARDE ESTAS INSTRUCCIONES

EN	Instructions for use	3
FR	Mode d'emploi	13
ES	Instrucciones de uso	23

INSTRUCTIONS FOR USE

BONECO F120

TABLE OF CONTENTS

Technical data	5
Introduction	6
Items included	6
Overview and part names	7
Start-up	8
Handling	9
Handling	9
Alignment	9
Positioning tips	10
Notes on output	10
Air-Conditioning System (AC)	10
Fresh air	10
Multiple floors	10
Rooms with high ceilings	10
Cleaning	11
Safety instructions	11
Cleaning the housing	11
Cleaning the fan blades	11

TECHNICAL DATA

Technical data*

Model	BONECO F120
Power supply voltage	120 V / 60 Hz
Power consumption	25 W (max. level)
Operation noise level	55 dB(A) (max. level)
Air flow	359 CFM (610 m ³ /h)
Air-speed	13 ft/sec (4.1 m/sec)
Dimensions L×W×H	11 × 11 × 21.3 in. (278 × 278 × 540 mm)
Weight	6.4 lb. (2.9 kg)

* Subject to change

INTRODUCTION

DEAR CUSTOMER,

Congratulations on your purchase of the BONECO F120 Air Shower Fan. This high-performance unit seamlessly adapts to meet your needs. When set to the lower output level, it provides a pleasant breeze in your home on hot days. On the other hand, if you use an air conditioner, the powerful fan distributes the air throughout the room to ensure a uniform temperature.


In developing the BONECO F120 Air Shower Fan, low maintenance and durability were of primary importance. The fan blade's one-of-a-kind shape creates a uniform air flow using minimal energy, which is also good for the environment. The elegant design harmonizes with any decorative style so that you can use your BONECO F120 Air Shower Fan throughout the entire year.

**We hope you enjoy your new
BONECO F120 Air Shower Fan!**


ITEMS INCLUDED



BONECO F120
Air Shower System



Manual



Safety instructions

OVERVIEW AND PART NAMES



- 1 Output regulator
- 2 Fan unit
- 3 Base with power cord

START-UP**1**

Place the BONECO F120 on a level, stable surface.

2

Plug the power cord into a power outlet.

3

Adjust the output using the control.

HANDLING

HANDLING


The BONECO F120 has a design that makes it really easy to operate. The output is adjusted in three levels using a single control: 0 > I > II > III



ALIGNMENT

The fan unit can be manually tilted 270 degrees.

 The fan unit does not rotate a full 360 degrees.



POSITIONING TIPS

NOTES ON OUTPUT

The BONECO F120 Air Shower Fan is equipped with a high-performance fan that can move large amounts of air. Making use of this feature: Guide the air in a specific direction to achieve a uniform room climate. The following examples illustrate how to do this.

AIR-CONDITIONING SYSTEM (AC)

An air conditioner distributes temperature in various ways. Use the BONECO F120 to move the warm air towards the air-conditioning system. This can be done directly or indirectly via air circulation, as shown in this image.



MULTIPLE FLOORS

In the summer, it can become hot and muggy on the upper floors. The powerful fan of the BONECO F120 directs cool air from the ground floor to multiple floors achieving a uniform temperature.



FRESH AIR

The BONECO F120 helps you achieve better ventilation indoors. If cross-ventilation is not created, guide fresh air directly from the window into the desired room.



ROOMS WITH HIGH CEILINGS

In air-conditioned rooms with high ceilings, the cold air sinks to the floor while the warm air rises to the ceiling. Point the BONECO F120 straight up for an air-shower sensation.



CLEANING

SAFETY INSTRUCTIONS

 Always unplug the BONECO F120 before you start cleaning it! Failure to do so can result in electric shock and fatal injury!

 Do not use alcohol or corrosive cleaning agents for cleaning.

 Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

 To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.

CLEANING THE HOUSING

The BONECO F120 is designed for low-maintenance operation, even when used over many years. In most cases, a dry cloth can be used for cleaning.


If stubborn dirt is present, clean the housing using a damp cloth. Add a small amount of dishwashing detergent to the water.

CLEANING THE FAN BLADES

1. Tilt the fan unit upwards and loosen the safety screw.



2. Remove the front grill by slightly turning it counter-clockwise.



3. Unscrew the safety screw in the middle by turning it clockwise.



4. Remove the fan blade and clean it with a damp cloth.

5. Put the unit back together by following the steps in reverse order.

6. Attach the front grill with the safety screw. When doing so, pay attention to the position of the screw on the front grill.

